

home (<https://support.thinklucid.com>) / Knowledge Base (<https://support.thinklucid.com/knowledge-base-articles/>) / Camera Features (<https://support.thinklucid.com/kb/camera-features/>) / Pixel Formats – Area Scan

🔍 Enter a search term. (Login to see full results)



Pixel Formats – Area Scan

👁 451 views 🍌 0 📅 September 29, 2025 🔄 Updated on November 26, 2025

Looking for Line Scan or 3D Pixel Formats? Visit our **Line Scan Pixel Format**



(<https://support.thinklucid.com/knowledgebase/pixel-formats-line-scan/>) and our **3D Pixel Format** (<https://support.thinklucid.com/knowledgebase/pixel-formats-3d/>) pages for more information.

Introduction

Understanding pixel formats allow you to understand how images are put together. More specifically, understanding these pixel formats will help you if you need to extract specific information from the pixels in the image that you receive from the camera.

Jump to:

Color-processed pixel formats

RGB8
RGB12p
RGB16
RGB24
BGR8
BGR12p
BGR16
BGR24

Bayer RG formats

BayerRG8
BayerRG10
BayerRG10p
BayerRG10Packed
BayerRG12
BayerRG12p



BayerRG12Packed
BayerRG16
BayerRG24

Dual Bayer RG formats

DualBayerRG8
DualBayerRG10
DualBayerRG10p
DualBayerRG10Packed
DualBayerRG12
DualBayerRG12p
DualBayerRG12Packed
DualBayerRG16

Polarized pixel formats

PolarizedAngles_0d_45d_90d_135d_Mono8
PolarizedStokes_S0_S2_S1_S3_Mono8

PolarizedDolpAolp_Mono8
PolarizedDolpAolp_Mono12p
PolarizedDolp_Mono8
PolarizedDolp_Mono12p
PolarizedAolp_Mono8
PolarizedAolp_Mono12p

Basic mono pixel formats

Mono8
Mono10
Mono10p
Mono10Packed
Mono12
Mono12p
Mono12Packed
Mono16

YCbCr pixel formats: basic and subsampled

YCbCr – Basic
YCbCr– Subsampled


QOI pixel formats

Description

Color-processed pixel formats

FOR YCbCr and YUV, see the separate sections for these formats.

RGB8



RGB12p




7	6	5	4	3	2	1	0	
7								0
Byte 1								
3	2	1	0	11	10	9	8	
7								0
Byte 2								
11	10	9	8	7	6	5	4	
7								0
Byte 3								
7	6	5	4	3	2	1	0	
7								0
Byte 4								
3	2	1	0	11	10	9	8	
7								0
Byte 5								
3	2	1	0	7	6	5	4	
7								0
Byte 6								
7	6	5	4	3	2	1	0	
7								0
Byte 7								
3	2	1	0	11	10	9	8	
7								0
Byte 8								
3	2	1	0	7	6	5	4	
7								0

RGB16

Byte 0							
7	6	5	4	3	2	1	0
7							
0							
Byte 1							
15	14	13	12	11	10	9	8
7							
0							
Byte 2							
7	6	5	4	3	2	1	0
7							
0							
Byte 3							
15	14	13	12	11	10	9	8
7							
0							
Byte 4							
7	6	5	4	3	2	1	0
7							
0							
Byte 5							
15	14	13	12	11	10	9	8
7							
0							

RGB24

Byte 0							
7	6	5	4	3	2	1	0
							0
Byte 1							



15	14	13	12	11	10	9	8
7							0
Byte 2							
23	22	21	20	19	18	17	16
7							0
Byte 3							
7	6	5	4	3	2	1	0
7							0
Byte 4							
15	14	13	12	11	10	9	8
7							0
Byte 5							
23	22	21	20	19	18	17	16
7							0
Byte 6							
7	6	5	4	3	2	1	0
7							0
Byte 7							
15	14	13	12	11	10	9	8
7							0
Byte 8							
23	22	21	20	19	18	17	16
7							0


BGR8

Byte 0							
7	6	5	4	3	2	1	0
7							0
Byte 1							
7	6	5	4	3	2	1	0
7							0
Byte 2							
7	6	5	4	3	2	1	0
7							0


BGR12p

Byte 0							
7	6	5	4	3	2	1	0
7							0
Byte 1							
3	2	1	0	11	10	9	8
7							0
Byte 2							
11	10	9	8	7	6	5	4
7							0
Byte 3							
7	6	5	4	3	2	1	0
7							0
Byte 4							
3	2	1	0	11	10	9	8
7							0
Byte 5							





BGR16



BGR24



7	6	5	4	3	2	1	0
7 0							
Byte 7							
15	14	13	12	11	10	9	8
7 0							
Byte 8							
23	22	21	20	19	18	17	16
7 0							

Bayer RG formats

The BayerRG pixel formats are repetitions of a 2x2 grid comprising a top row containing one red (R) and one green (G) filter, and a bottom row containing one green (G) and one blue (B) filter.


Bayer formats are raw pixel formats.

BayerRG8


Byte 0							
7	6	5	4	3	2	1	0
70							
Byte 1							
7	6	5	4	3	2	1	0
70							
Byte 2							
7	6	5	4	3	2	1	0
70							
Byte 3							
7	6	5	4	3	2	1	0
70							
Byte n							
7	6	5	4	3	2	1	0
70							
Byte n+1							
7	6	5	4	3	2	1	0
70							
Byte n+2							
7	6	5	4	3	2	1	0
70							
Byte n+3							
7	6	5	4	3	2	1	0
70							

BayerRG10


Byte 0							
7	6	5	4	3	2	1	0
7 0							
Byte 1							
pad	pad	pad	pad	pad	pad	9	8
7 0							
Byte 2							
7	6	5	4	3	2	1	0
7 0							



BayerRG10p



BayerRG10Packed




Byte 1							
pad	pad	1	0	pad	pad	1	0
7							0
Byte 2							
9	8	7	6	5	4	3	2
7							0
Byte 1.5n							
9	8	7	6	5	4	3	2
7							0
Byte 1.5n+1							
pad	pad	1	0	pad	pad	1	0
7							0
Byte 1.5n+2							
9	8	7	6	5	4	3	2
7							0

BayerRG12

Byte 0							
7	6	5	4	3	2	1	0
7							0
Byte 1							
pad	pad	pad	pad	11	10	9	8
7							0
Byte 2							
7	6	5	4	3	2	1	0
7							0
Byte 3							
pad	pad	pad	pad	11	10	9	8
7							0
Byte 2n							
7	6	5	4	3	2	1	0
7							0
Byte 2n+1							
pad	pad	pad	pad	11	10	9	8
7							0
Byte 2n+2							
7	6	5	4	3	2	1	0
7							0
Byte 2n+3							
pad	pad	pad	pad	11	10	9	8
7							0

BayerRG12p

Byte 0							
7	6	5	4	3	2	1	0
7							0
Byte 1							
3	2	1	0	11	10	9	8
7							0
Byte 2							
11	10	9	8	7	6	5	4 
7							0


Byte 1.5n							
7	6	5	4	3	2	1	0
7 0							
Byte 1.5n+1							
3	2	1	0	11	10	9	8
7 0							
Byte 1.5n+2							
11	10	9	8	7	6	5	4
7 0							

BayerRG12Packed













Byte 0							
11	10	9	8	7	6	5	4
70							
Byte 1							
3	2	1	0	3	2	1	0
70							
Byte 2							
11	10	9	8	7	6	5	4
70							
Byte 1.5n							
11	10	9	8	7	6	5	4
70							
Byte 1.5n+1							
3	2	1	0	3	2	1	0
70							
Byte 1.5n+2							
11	10	9	8	7	6	5	4
70							

BayerRG16

Byte 0							
7	6	5	4	3	2	1	0
70							
Byte 1							
15	14	13	12	11	10	9	8
70							
Byte 2							
7	6	5	4	3	2	1	0
70							
Byte 3							
15	14	13	12	11	10	9	8
70							
Byte 2n							
7	6	5	4	3	2	1	0
70							
Byte 2n+1							
15	14	13	12	11	10	9	8
70							
Byte 2n+2							
7	6	5	4	3	2	1	0
70							



BayerRG24



Dual Bayer formats

The Dual Bayer pixel formats are for the dual extended-head cameras.

In the diagram below, Imager 1 pixels are shown with a regular border around each bit, and Imager 2 pixels are shown with a bold line around each bit.

Imager 1:



Imager 2:



DualBayerRG8

Byte 0							
7	6	5	4	3	2	1	0
7							
0							
Byte 1							
7	6	5	4	3	2	1	0
7							
0							
Byte 2							
7	6	5	4	3	2	1	0
7							
0							
Byte 3							
7	6	5	4	3	2	1	0
7							
0							
Byte 2n							
7	6	5	4	3	2	1	0
7							
0							
Byte 2n+1							
7	6	5	4	3	2	1	0
7							
0							
Byte 2n+2							
7	6	5	4	3	2	1	0
7							
0							
Byte 2n+3							
7	6	5	4	3	2	1	0
7							
0							


DualBayerRG10

Byte 0							
7	6	5	4	3	2	1	0
70							
Byte 1							
pad	pad	pad	pad	pad	pad	9	8
70							
Byte 2							
7	6	5	4	3	2	1	0
70							
Byte 3							
pad	pad	pad	pad	pad	pad	9	8
70							
Byte 4							
7	6	5	4	3	2	1	0
70							
Byte 5							
pad	pad	pad	pad	pad	pad	9	8
70							
Byte 6							
7	6	5	4	3	2	1	0
70							


Byte 7	pad	pad	pad	pad	pad	pad	9	8
7								0
Byte 4n	7	6	5	4	3	2	1	0
7								0
Byte 4n+1	pad	pad	pad	pad	pad	pad	9	8
7								0
Byte 4n+2	7	6	5	4	3	2	1	0
7								0
Byte 4n+3	pad	pad	pad	pad	pad	pad	9	8
7								0
Byte 4n+4	7	6	5	4	3	2	1	0
7								0
Byte 4n+5	pad	pad	pad	pad	pad	pad	9	8
7								0
Byte 4n+6	7	6	5	4	3	2	1	0
7								0
Byte 4n+8	pad	pad	pad	pad	pad	pad	9	8
7								0

DualBayerRG10p


Byte 0	7	6	5	4	3	2	1	0
7								0
Byte 1	5	4	3	2	1	0	9	8
7								0
Byte 2	3	2	1	0	9	8	7	6
7								0
Byte 3	1	0	9	8	7	6	5	4
7								0
Byte 4	9	8	7	6	5	4	3	2
7								0
Byte 2.5n	7	6	5	4	3	2	1	0
7								0
Byte 2.5n+1	5	4	3	2	1	0	9	8
7								0
Byte 2.5n+2								



DualBayerRG10Packed



DualBayerRG12



pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 2

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 3

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 4

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 5

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 6

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 7

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 4n

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 4n+1

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 4n+2

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 4n+3

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 4n+4

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 4n+5

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

Byte 4n+6

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 4n+7

pad	pad	pad	pad	11	10	9	8
-----	-----	-----	-----	----	----	---	---

7 0

DualBayerRG12p

Byte 0

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

7 0

Byte 1

3	2	1	0	11	10	9	8
---	---	---	---	----	----	---	---






DualBayerRG12Packed





DualBayerRG16



2/2/26, 2:54 p.m.

Pixel Formats – Area Scan | LUCID Support & Help

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

70

Byte 4n+3

15	14	13	12	11	10	9	8
----	----	----	----	----	----	---	---

70

Byte 4n+4

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

70

Byte 4n+5

15	14	13	12	11	10	9	8
----	----	----	----	----	----	---	---

70

Byte 4n+6

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

70

Byte 4n+7

15	14	13	12	11	10	9	8
----	----	----	----	----	----	---	---

70

Polarized pixel formats

These pixel formats are for LUCID's polarized-light cameras.

PolarizedAngles_0d_45d_90d_135d_RGB8
32 bits per pixel

Byte 0

0	0	0	0	0	0	0	0
---	---	---	---	---	---	---	---

70

Byte 1

45	45	45	45	45	45	45	45
----	----	----	----	----	----	----	----

70

Byte 2

90	90	90	90	90	90	90	90
----	----	----	----	----	----	----	----

70

Byte 3

135	135	135	135	135	135	135	135
-----	-----	-----	-----	-----	-----	-----	-----

70

(0,0) pixel

Byte 0

0	0	0	0	0	0	0	0
---	---	---	---	---	---	---	---

70

Byte 1

45	45	45	45	45	45	45	45
----	----	----	----	----	----	----	----

70

Byte 2

90	90	90	90	90	90	90	90
----	----	----	----	----	----	----	----

70

Byte 3

135	135	135	135	135	135	135	135
-----	-----	-----	-----	-----	-----	-----	-----

70

(1,0) pixel

Byte 0

0	0	0	0	0	0	0	0
---	---	---	---	---	---	---	---


70

↑




PolarizedAngles_0d_45d_90d_135d_Mono8

32 bits per pixel




PolarizedStokes_S0_S2_S1_S3_Mono8

32 bits per pixel




PolarizedDoLPAoLP_Mono8

16 bits per pixel




PolarizedDoLPAoLP_Mono12p

24 bits per pixel




PolarizedDoLP_Mono8

8 bits per pixel




PolarizedDoLP_Mono12p

12 bits per pixel



PolarizedAoLP_Mono8

8 bits per pixel



PolarizedAoLP_Mono12p

12 bits per pixel

11	10	9	8	7	6	5	4	3	2	1	0	AoLP Pixel 1	
11	10	9	8	7	6	5	4	3	2	1	0		AoLP Pixel 2
Byte 0													
7		6		5		4		3		2		1	0
70													
Byte 1													
3		2		1		0		11		10		9	8
70													
Byte 2													
11		10		9		8		7		6		5	4
70													

Mono pixel formats

Mono pixel formats supported by LUCID cameras are shown below.

Mono8

8 bits per pixel

Byte 0							
7	6	5	4	3	2	1	0
70							

Mono10

10 bits per pixel

9	8	7	6	5	4	3	2	1	0	Pixel 1
9	8	7	6	5	4	3	2	1	0	
Byte 0										
7	6	5	4	3	2	1	0			
70										
Byte 1										
pad	pad	pad	pad	pad	pad	pad	9	8		
70										
Byte 2										
7	6	5	4	3	2	1	0			
70										
Byte 3										
pad	pad	pad	pad	pad	pad	pad	9	8		
70										

Mono10p

10 bits per pixel

9	8	7	6	5	4	3	2	1	0	Pixel 1
9	8	7	6	5	4	3	2	1	0	Pixel 2
9	8	7	6	5	4	3	2	1	0	Pixel 3
9	8	7	6	5	4	3	2	1	0	Pixel 4
Byte 0										

7	6	5	4	3	2	1	0	
7								0
Byte 1								
5	4	3	2	1	0	9	8	
7								0
Byte 2								
3	2	1	0	9	8	7	6	
7								0
Byte 3								
1	0	9	8	7	6	5	4	
7								0
Byte 4								
9	8	7	6	5	4	3	2	
7								0

Mono10Packed

10 bits per pixel

9	8	7	6	5	4	3	2	1	0	Pixel 1						
9	8	7	6	5	4	3	2	1	0		Pixel 2					
Byte 0																
9		8		7		6		5		4		3		2		
7																0
Byte 1																
pad			pad			1	0	pad			pad			1	0	
7																0
Byte 2																
9		8		7		6		5		4		3		2		
7																

Mono12

12 bits per pixel


11	10	9	8	7	6	5	4	3	2	1	0	Pixel 1	
11	10	9	8	7	6	5	4	3	2	1	0		
Pixel 2													
Byte 0													
7		6		5		4		3		2		1	0
7													0
Byte 1													
pad		pad		pad		pad		11		10		9	8
7													0
Byte 2													
7		6		5		4		3		2		1	0
7													0
Byte 3													
pad		pad		pad		pad		11		10		9	8
7													0

Mono12p


12 bits per pixel

11	10	9	8	7	6	5	4	3	2	1	0	Pixel 1
11	10	9	8	7	6	5	4	3	2	1	0	

Byte 0









Mono12Packed

12 bits per pixel




Mono16

16 bits per pixel



Linescan ROI



YCbCr Pixel Formats: Basic and subsampled

YCbCr Pixel Formats – Basic

All basic (non-subsampled) YCbCr pixel formats capture one luma (Y) component and two chroma components (Cr and Cb). These basic pixel formats are also known as YCbCr444 formats. Note: For YUV8, YUV16, and YUV24, substitute U for Cb (and V for Cr) in the diagrams below.

YCbCr8



7	6	5	4	3	2	1	0	Cb
7	6	5	4	3	2	1	0	Cr

Byte 0

7	6	5	4	3	2	1	0	Y Pixel 1
---	---	---	---	---	---	---	---	------------------

Byte 1

7	6	5	4	3	2	1	0	Cb
---	---	---	---	---	---	---	---	-----------

Byte 2

7	6	5	4	3	2	1	0	Cr
---	---	---	---	---	---	---	---	-----------

YCbCr16

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 1
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

7	6	5	4	3	2	1	0	Y	15	14	13	12	11	10	9	8	Y Pixel 1
7	6	5	4	3	2	1	0	Cb	15	14	13	12	11	10	9	8	Cb
7	6	5	4	3	2	1	0	Cr	15	14	13	12	11	10	9	8	Cr Pixel 1

YCbCr24

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 1
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

7	6	5	4	3	2	1	0	Y	15	14	13	12	11	10	9	8	Y	23	22	21	20	19	18	17	16	Y Pixel 1
7	6	5	4	3	2	1	0	Cb	15	14	13	12	11	10	9	8	Cb	23	22	21	20	19	18	17	16	Cb
7	6	5	4	3	2	1	0	Cr	15	14	13	12	11	10	9	8	Cr	23	22	21	20	19	18	17	16	Cr Pixel 1

YCbCr Pixel Formats – Subsampled

In subsampled pixel formats, the luma value in each pixel is sampled (read), but the chroma values are not. The purpose of subsampling is to reduce the amount of data. “422” subsampling means that that two samples each of Cb and Cr is recorded for every four samples of luma. Similarly, “411” subsampling means that that one sample each of Cb and Cr is recorded for every four samples of luma. In each subsampling scheme, Y1, Y2, Y3, and Y4 are luma values from pixels 1 to 4 respectively. Cb and Cr are averages calculated from the available pixels. YCbCr422_8_CbYCrY means that “422” subsampling is being used with 8 bits per channel, and the order of bytes is Y, Cb, Y, Cr. Note: The patterns shown below applies to YCbCr formats. To see the equivalent YUV formats, substitute U for Cb (and V for Cr).

YCbCr422_8_CbYCrY

7	6	5	4	3	2	1	0	Y Pixel 1
7	6	5	4	3	2	1	0	Cb
7	6	5	4	3	2	1	0	Cr
7	6	5	4	3	2	1	0	Y Pixel 2
7	6	5	4	3	2	1	0	Cb

7	6	5	4	3	2	1	0	Cr
---	---	---	---	---	---	---	---	-----------

Byte 0

7	6	5	4	3	2	1	0	Cb Pixel 1
---	---	---	---	---	---	---	---	-------------------

Byte 1

7	6	5	4	3	2	1	0	Y
---	---	---	---	---	---	---	---	----------

Byte 2

7	6	5	4	3	2	1	0	Cr
---	---	---	---	---	---	---	---	-----------

Byte 3

7	6	5	4	3	2	1	0	Y
---	---	---	---	---	---	---	---	----------

YCbCr422_16_CbYCrY

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 1
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 2
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

Byte 0

7	6	5	4	3	2	1	0	Cb
---	---	---	---	---	---	---	---	-----------

Byte 2

7	6	5	4	3	2	1	0	Y
---	---	---	---	---	---	---	---	----------

Byte 4

7	6	5	4	3	2	1	0	Cr
---	---	---	---	---	---	---	---	-----------

Byte 6

7	6	5	4	3	2	1	0	Y
---	---	---	---	---	---	---	---	----------

Byte 1

15	14	13	12	11	10	9	8	Cb Pixel 1
----	----	----	----	----	----	---	---	-------------------

Byte 3

15	14	13	12	11	10	9	8	Y
----	----	----	----	----	----	---	---	----------

Byte 5

15	14	13	12	11	10	9	8	Cr Pixel 1
----	----	----	----	----	----	---	---	-------------------

Byte 7

15	14	13	12	11	10	9	8	Y Pixel 1
----	----	----	----	----	----	---	---	------------------

YCbCr422_24_CbYCrY

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 1
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 2
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

Byte 0

7	6	5	4	3	2	1	0	Cb
---	---	---	---	---	---	---	---	-----------

Byte 3

7	6	5	4	3	2	1	0	Y
---	---	---	---	---	---	---	---	----------

Byte 6

7	6	5	4	3	2	1	0	Cr
---	---	---	---	---	---	---	---	-----------

Byte 9

7	6	5	4	3	2	1	0	Y
---	---	---	---	---	---	---	---	----------

Byte 1

15	14	13	12	11	10	9	8	Cb
----	----	----	----	----	----	---	---	-----------

Byte 4

15	14	13	12	11	10	9	8	Y
----	----	----	----	----	----	---	---	----------

Byte 7

15	14	13	12	11	10	9	8	Cr
----	----	----	----	----	----	---	---	-----------

Byte 10

15	14	13	12	11	10	9	8	Y
----	----	----	----	----	----	---	---	----------

Byte 2

23	22	21	20	19	18	17	16	Cb Pixel 1
----	----	----	----	----	----	----	----	-------------------

Byte 5

23	22	21	20	19	18	17	16	Y
----	----	----	----	----	----	----	----	----------

Byte 8

23	22	21	20	19	18	17	16	Cr Pixel 1
----	----	----	----	----	----	----	----	-------------------

Byte 11

23	22	21	20	19	18	17	16	Y Pixel 1
----	----	----	----	----	----	----	----	------------------

YCbCr411_8_CbYYCrYY

7	6	5	4	3	2	1	0	Y Pixel 1
7	6	5	4	3	2	1	0	Cb
7	6	5	4	3	2	1	0	Cr

7	6	5	4	3	2	1	0	Y Pixel 2
7	6	5	4	3	2	1	0	Cb

7	6	5	4	3	2	1	0	Cr
7	6	5	4	3	2	1	0	Y Pixel 3
7	6	5	4	3	2	1	0	Cb
7	6	5	4	3	2	1	0	Cr
7	6	5	4	3	2	1	0	Y Pixel 4
7	6	5	4	3	2	1	0	Cb
7	6	5	4	3	2	1	0	Cr

Byte 0								Cb Pixel 1
7	6	5	4	3	2	1	0	
Byte 1								Y1
7	6	5	4	3	2	1	0	
Byte 2								Y2
7	6	5	4	3	2	1	0	
Byte 3								Cr
7	6	5	4	3	2	1	0	
Byte 4								Y3
7	6	5	4	3	2	1	0	
Byte 5								Y4
7	6	5	4	3	2	1	0	

YCbCr411_16_CbYYCrYY

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 1
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 2
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 3
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 4
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

Byte 0								Cb	Byte 1								Cb Pixel 1
7	6	5	4	3	2	1	0		15	14	13	12	11	10	9	8	
Byte 2								Y1	Byte 3								Y1
7	6	5	4	3	2	1	0		15	14	13	12	11	10	9	8	
Byte 4								Y2	Byte 5								Y2 Pixel 1
7	6	5	4	3	2	1	0		15	14	13	12	11	10	9	8	
Byte 6								Cr	Byte 7								Cr Pixel 1
7	6	5	4	3	2	1	0		15	14	13	12	11	10	9	8	
Byte 8								Y3	Byte 9								Y3 Pixel 1
7	6	5	4	3	2	1	0		15	14	13	12	11	10	9	8	
Byte 10								Y4	Byte 11								Y4 Pixel 1
7	6	5	4	3	2	1	0		15	14	13	12	11	10	9	8	

YCbCr411_24_CbYYCrYY

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 1
----	----	----	----	----	----	----	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---	---	------------------

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 2
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 3
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Y Pixel 4
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cb
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Cr

Byte 0	7	6	5	4	3	2	1	0	Cb	Byte 1	15	14	13	12	11	10	9	8	Cb	Byte 2	23	22	21	20	19	18	17	16	Cb Pixel 1
Byte 3	7	6	5	4	3	2	1	0	Y1	Byte 4	15	14	13	12	11	10	9	8	Y1	Byte 5	23	22	21	20	19	18	17	16	Y1
Byte 6	7	6	5	4	3	2	1	0	Y2	Byte 7	15	14	13	12	11	10	9	8	Y2	Byte 8	23	22	21	20	19	18	17	16	Y2 Pixel 1
Byte 9	7	6	5	4	3	2	1	0	Cr	Byte 10	15	14	13	12	11	10	9	8	Cr	Byte 11	23	22	21	20	19	18	17	16	Cr Pixel 1
Byte 12	7	6	5	4	3	2	1	0	Y3	Byte 13	15	14	13	12	11	10	9	8	Y3	Byte 14	23	22	21	20	19	18	17	16	Y3 Pixel 1
Byte 15	7	6	5	4	3	2	1	0	Y4	Byte 16	15	14	13	12	11	10	9	8	Y4	Byte 17	23	22	21	20	19	18	17	16	Y4 Pixel 1

QOI Pixel Formats

Quite OK Image Format (QOI) is a lossless image compression method implemented in LUCID’s Triton cameras. For information on how to use QOI pixel formats, see the knowledge base Using QOI with LUCID Cameras (https://support.thinklucid.com/knowledgebase/using_qoi_with_lucid_cameras/).

Examples of QOI pixel formats:

- QOI_Mono8
- QOI_BayerRG8
- QOI_RGB8
- QOI_BGR8
- QOI_YCbCr8
- QOI_YCbCr8_CbYCr

Was this helpful?





Yes

No

Related Articles

- Using GigE Vision RDMA Streaming Protocol in GigE Vision 3.0
(<https://support.thinklucid.com/knowledgebase/using-gige->
- Pixel Formats – 3D
(<https://support.thinklucid.com/knowledgebase/pixel-formats->

[vision-rdma-streaming-protocol-in-gige-vision-3-0/\)](#)[3d/\)](#)

-  [Pixel Formats – Line Scan](#)
(<https://support.thinklucid.com/knowledgebase/pixel-formats-line-scan/>)
-  [Using QOI with LUCID Cameras](#)
(https://support.thinklucid.com/knowledgebase/using_qoi_with_
-  [Using Multiple Helios Cameras Simultaneously](#)
(<https://support.thinklucid.com/knowledgebase/using-multiple-helios-2-cameras-simultaneously/>)
-  [Shading Correction Control \(Atlas10\)](#)
(<https://support.thinklucid.com/knowledgebase/shading-correction-control-atlas10/>)

Didn't find your answer? @ [Contact Us](#)

➦ [Using QOI with LUCID Cameras \(https://support.thinklucid.com/knowledgebase/using_qoi_with_lucid_cameras/\)](#)

[Pixel Formats – Line Scan \(https://support.thinklucid.com/knowledgebase/pixel-formats-line-scan/\)](#) ➦

© 2026 LUCID Vision Labs Inc.

Looking to purchase our cameras?

Visit the LUCID Webstore at thinklucid.com (<https://thinklucid.com>)

